

Scoreboard Quick Guide

Rules:

~ 14 Minute halves — Stop Clock

~ 3 minute halftime


~ Clock stops for any whistle or dead ball.

Keeping Score:

1. Look at the Scoresheet to determine which team is home and which is away.
2. Push the correct score button when that team scores.

HOME

AWAY



The Clock:

Start

Stop

Start and stop button placement will vary by scoreboard.

Set Time:

1. Find the 'Set Time' Button. Varies by controller.
2. Type in amount of time needed on number pad.
3. Hit 'Enter'